


Variants HG G-19370-B & HG G-19380-B | Guide Wire / Energy Track



The inductive guidance sensor HG G-19370 / HG G-19380 is used for the inductive track guidance of Automated Guided Vehicles (AGV). Up to 5 different guide wire frequencies may be detected and evaluated simultaneously. Alternatively a ground installation for the contact-less inductive energy transmission with two wires (energy track) can be used for the track guidance.


The guide wire frequencies to be detected are configured via the USB interface. The

guidance sensor is available in different variants for common energy tracks (s. table to the right). Additionally an incremental encoder for the measurement of distance or speed may be connected directly to the sensor.

Functional Principle (using Guide Wire as an Example)

A frequency generator feeds a current into a guide wire installed in the ground. Along this wire an alternat-

ing magnetic field is generated. When the sensor is moved along the guide wire two characteristic voltages are induced in its horizontal coils and evaluated. Thus for each frequency a sum and difference signal is calculated. *Usum* is used to detect whether a track is available (signal *Detect* when a threshold is exceeded). *Udiff* shows maxima at both sides of the wire and crosses zero directly above the wire. Udiff is used to control the vehicle.



Overview

- Inductive guidance sensor for the track guidance of automated guided vehicles (AGV)
- Guide wire, 5 programmable simultaneously usable frequencies (2 – 20 kHz)
- If there is an existing ground installation for the contact-less inductive
 energy transmission (energy track)
 this can also be used for the track
 guidance, see table Variants below.
 Within the zone of influence of an
 active energy track guide wire signals can not be used.
- Works with single wire and double wire installations
- Reading height: 40 200 mm, nominal reading height 60 mm, customizable via programmable gain
- IP 54, Indoor
- Version ZB: CAN/CANopen® interface
- Version YB: PROFINET® interface
- USB interface (configuration via USB Virtual Port Driver)
- Possibility to connect and evaluate an incremental encoder

Versions/Variants						
HG G-19370	ZB	CAN	Energy track 20/25 kHz,			
	ΥB	Profinet	140 mm wire spacing, 85 A			
HG G-19380	ZB	CAN	Energy track 140 kHz,			
	ΥB	Profinet	110 mm wire spacing, 45 A			

1 Date: 26.10.2023 | Revision 07 / English | Author(s): RAD / LF

Product page: http://goetting-agv.com/components/19370-19380



Mounting Notes

- The sensor has two bore holes for screws with which it can be mounted (see figure to the right).
- The inductive guidance sensor is to be mounted diagonally to the direction of travel with the connectors facing upwards.
- The recommended reading height is 40 to 200 mm from the bottom edge of the casing to the guide wire. Nominal reading height is 60 mm, programmable gain for different reading heights.
- Additional magnetic fields close to the sensor can affect the system characteristics.
- The limit value for the magnetic field of e.g. transverters/engines/wire connections at the position of the inductive guidance sensor is circa 0,01 A/m


Guide Wire / Energy Track

- Inside the track a guide wire is layed that is operated in the frequency range 2 to 20 kHz.
- If there is an existing ground installation for the contact-less inductive energy transmission this can also be used for the track guidance. These energy tracks are supported in the implementations listed in table Variants on the front. A matching variant of the inductive guidance sensor has to be used. Within the zone of influence of an active energy track guide wire signals can not be used.
- The inductive guidance sensor can follow turn-offs in guide wire installations by using different frequencies for the different wires.
- The inductive guidance sensor can not follow turn-offs in energy track installations. Thus the energy track may not have switch points. For energy track installations with switch points Götting has different antennas with more than one detection system.

Additional Products / Accessories				
HW CAB00008	ST1: Cable PUR, 5 m, M12			
	elbow socket, open end			
HW CON00055	ST2: Variant ZB – CAN-			
HW CONOUSS	Bus Terminator			
	ST3: Variant ZB – CAN-			
HW CAB00064	Bus cable, 10 m, with			
	shielding, M12 socket			
	straight, open end			
HG G-20960ZA	Connection box			

Götting Product IDs (order codes)				
HG G-19380ZB				
	Production series (no functional relevance) Functional Model / Version Identification Number / Type G: Device K: Component S: System W: Software HG: Götting HW: Resale			

Casing Dimensions / Mounting (all Variants)



Pin assignments, all connectors M12							
	ST1		S.	Т2	ST3		
	all Variants		ants ZB / CAN		ZB / CAN	YB / PROFINET	
Pin	8 pin, A-coded, male		5 pin, A-coded, female	4 pin, D-coded, female	5 pin, A-coded, male	4 pin, D-coded, female	
1	VBUS (US	SB 5V-) to +UB	_	TX+	_	TX+	
2	GND		+UB	RX+	+UB	RX+	
3	Track A	Incremental	GND	TX-	GND	TX-	
4	Track B	Encoder	CAN_H	RX-	CAN_H	RX-	
5	Index Z		CAN_L		CAN_L		
6	D+ (USB)						
7	D- (USB)						
8	GND						
	40 30 2 05 08 10 60 07		4 0 0 0 2 5 3	1 0 3	2 4	1 0 3	

Technical Data			
Dimensions	156,5 mm x max. 70 mm x 31 mm (W x H x D)		
Casing	Polycarbonate		
Weight	approx. 200 g		
Protection class	IP 54, Indoor		
Reading distance	40 – 200 mm		
Nominal reading distance	60 mm (preset) Different reading distances via programmable gain		
Relative humidity	95 % @ 25° C (without condensation)		
Temperature ranges	Operation: -20° C to +50° C / Storage: -20° C to +70° C		
Voltage supply	5V (USB, configuration) / Nominal (vehicle): 12 VDC – 24 VDC / Maximum: 10 VDC – 30 VDC		
Current consumption	HG G-19370ZB/HG G-19380ZB (CAN): 60 mA @ 24 V HG G-19370YB/HG G-19380YB (PROFINET): 110 mA @ 24 V		
Frequencies	 5 programmable guide wire frequencies, simultaneously usable, 2 – 20 kHz, 100 Hz resolution 1 programmable frequency for an energy track 		
Energy track	Guidance sensor variants for common energy tracks (see table Variants on the front)		
Measuring rate	100 Hz (every 10 ms a new value is calculated)		
Connectors	3x M12 circular connectors, see table Pin Assignments above		
USB	Configuration / Firmware Update (emulation of a serial interface)		
Incremental encoder	Input for the processing of an incremental encoder. All incremental encoders can be used that have a switching threshold > 10 V between high level and low level (typically 24V incremental encoders).		

© Götting KG – We reserve the right to perform modifications to our products, particularly technical improvements and further developments.

